

## Railway **Wheelchair lift automatic**





## Wheelchair lift automatic

For persons with reduced mobility (PRM), the automatic wheelchair lift enables boarding and alighting at stations with different platform heights. The lift is installed in the rail vehicle and is therefore always available. A special feature of the lift is its fully automatic operation. At the push of a button, the lift is ready for use and can also be returned to its parking position, in which the door opening area is not impaired.

Our wheelchair lifts are customized and built according to your needs. Give us a call!

## Technical specification

Cycle time (PARK - LOWER LEVEL - PARK)	100 s
max. platform payload	360 kg
Lifting height	up to 800 mm
Platform size for wheelchair	800 x 1200 mm
max. platform speed	0.15 m/s
Supply voltage	400 VAC
Control voltage	110 VDC
Power consumption	1.1 kW
Weight (according to version)	300 kg
Dimension (according to version)	320 x 940 x 1450mm
Railway Standards	EN15085, EN50155, EN45545

# HÖGG

SIMPLIFY ENGINEERING

## SIMPLIFY ENGINEERING AG

AUSTRASSE 25  
CH-9630 WATTWIL  
TELEFON +41 71 987 73 50  
[WWW.SIMPLIFY-AG.CH](http://WWW.SIMPLIFY-AG.CH)  
[INFO@SIMPLIFY-AG.CH](mailto:INFO@SIMPLIFY-AG.CH)

